

Fingerprint Lock

USER MANUAL(V1.1)




Your finger is the key


Tip

- If the model you purchased is FL-U3&FL-U3BT, please press the button to wake up the lock, and then press the fingerprint to unlock or enter.

Set Administrator Account For The First Time




Second To Tenth User Fingerprint Entry



Specification

USB type-C input	DC5V/200mA
Battery	3.7V±100mAh ○ /120mAh ○ /280mAh ○
Fingerprint collecting time	≤0.5S
Fingerprint matching time	≤1S
Working temperature	-20℃~55℃
Working humidity	40%RH~90%RH
False reject rate	<1%
False accept rate	<0.002%
Memory capacity	10 sets ○ 40 sets ○



Tip: All products can delete fingerprints by the administrator, Bluetooth lock can also use APP to restore factory Settings.

Remarks

- The default first fingerprint is the administrator's account.
- The second to the tenth fingerprint is the user account, which needs the administrator's confirmation.
- When collecting fingerprints, one user collects as many fingerprints as possible.
- Please charge if the green light flashes when you touched the sensor. If the model you purchased is FL-U9 series fingerprint lock, the red light flashes. Please charge in time.
- The Bluetooth lock product only collects fingerprints 5 times.

指纹锁

产品说明书(V1.1)




你的手指就是钥匙


温馨提示

• 如果您购买的是FL-U3&FL-U3BT，则需要按压按键唤醒锁，再按指纹开锁或指纹录入。


首次设置管理员指纹



第二个到第十个用户指纹录入



删除指纹



温馨提示

• 所有产品需管理员才能清除指纹，带蓝牙锁也可用APP清除指纹或恢复出厂设置

备注

- 默认第一枚指纹为管理员指纹。
- 采集第二到第十枚指纹为用户指纹，采集时需要管理员授权确认。
- 指纹采集时，一个用户尽量多采集几组指纹。
- 当按压指纹传感器时绿色指示灯闪烁，请充电。如果您购买的是U9系列的指纹锁，会是红色指示灯闪烁，请及时充电。
- 蓝牙锁产品手指仅采集5次。

规格参数

充电电流	DC5V/200mA
电池容量	3.7V±100mAh ○ 120mAh ○ 280mAh ○
指纹采集时间	≤0.5S
指纹匹配时间	≤1S
工作温度	-20℃~55℃
工作湿度	40%RH~90%RH
拒真率	<1%
认假率	<0.002%
指纹容量	10组 ○ 40组 ○